



Ringo User Guide

Ringo is a fun ring tone manager for your Treo. Ringo lets you Personalize your Treo with MP3 Ring Tones and set custom tones and pictures for friends and groups.

Index

1. Downloading and Installing
2. Using Ringo – Getting started, the default settings.
3. Getting Mp3's
4. Adding/Importing Ringtones and the Ring tone Store
5. Announcing Callers
6. Incoming Call display
7. Ringo Features – setting up Friends and Groups
8. Advanced Ringo Features – Do Not Disturb, Volume Settings, Disable Ringo, Record your own Tones, Composing Ringtones and Checking for updates.
9. Registering Ringo

1. Downloading and Installing

When you download Ringo, it is a .zip file. Before you can install Ringo on your Treo, you need to extract the .prc file from the .zip file. You need to use an app like WinZip to do this. A Free Trial of WinZip is available at www.winzip.com. Mac Os X and Windows XP do come with 'unzipping' software automatically though.



The Launch Screen in Ringo

When you have opened WinZip, double click on ringo_installer.prc to add the application to your Hotsync Quick Install Manager.

Perform a Hotsync, and the installation will be complete.




Alternatively you can install directly to your Treo with an OTA (over the air) installation by accessing this page: www.electricpocket.com/ringo_installer.prc from your Treo's web browser.



Picking mp3 Tunes

2. Using Ringo – The Default Settings

When you launch Ringo it will open in the 'Ringo Ringtones' view – From here you can set a default ring and message tone and a default Incoming Call Display image – these settings will apply to all calls and messages.

There are 3 main views in Ringo - Friends () , Groups () and Default tones (). You can swap easily between them at any time by tapping on the correlating icon at the bottom of the screen.

Using an mp3 as a tone

Ringo lets you use ANY mp3 file as a ring tone. You do not have to use, as many phones make you, mp3's that have been specifically created as ringtones.

To make use of this feature you either need Ringo Pro or Pocket Tunes with Ringo basic. You can also buy an upgrade from Basic to Ringo pro at www.electricpocketshop.com

The mp3s you want to use as ringtones need to be saved to an SD memory card inserted in your Treo.

To use an mp3, tap 'Default Ringtone' or 'SMS tone', and select 'Pick mp3 Tune' from the drop down menu that appears. You can then browse and sample the mp3's on your card and select them as your tone.

3. Getting Mp3's

Any CD or music track from your collection can be converted easily to mp3 using the free itunes software at www.itunes.com

Mp3s can be found from so many sources. Countless sites sell music downloads and www.amazon.com offer hundreds of free mp3 downloads!

How to get them to your palm device

The mp3 files need to be saved to an SD memory card in order to play them on your palm. This is because they take up so much memory. Ringo will automatically search the SD card for any files it recognizes, but preferably they should be saved in the AUDIO directory.



Our Selection of Free Ringtones.
To use them in Ringo, you need
to save them to your SD card.


Transferring files to your SD card is easy. If you have a card reader/writer, then you will be familiar with how to copy them across. If not, it doesn't matter. You can hotsync mp3 files to your SD card using the Palm quick install tool when the card is inserted in your device.

Simply follow these steps:

1. Open Palm Quick install tool
2. Open windows explorer and find where you have saved your mp3 files.
3. Select the files you want to put on the card
4. Drag and drop the files to the 'Expansion card slot'



Adding Other Ringtones



Importing Tones



The Ringtone Store –
www.logogo.com

- area of the quick install window.
5. Hotsync to complete the transfer!

When you want to delete files from your card, this can be done again either using a card reader/writer or with a free application called Filez, available at www.palmgear.com, which will let you browse your SD card.

We also offer a free pack of mp3 ringtones at www.electricpocket.com/ringtones/ringtones.zip and www.amazon.com now has hundreds of free mp3 files for download.

4. Adding and importing Other Ringtones

The drop down menu that appears when you tap on either 'Default Ringtone' or 'SMS Tone' will also let you select any of the system ringtones or purchased ringtones that are on your Treo.

Select them from the list, or alternatively, tap on the 'Ringtone Store' option to activate a link to an online Ringtone shop to purchase more midi files.

If you have purchased a Ringtone or have midi files on your desktop that you would like to use in Ringo, you need to hotsync them to your memory card (use QuickInstall) and then import them from your memory card by tapping Menu>Tones>Import MIDI Tone in Ringo – you can do this when in the Default Tones View.

You can delete or send your favourite MIDI tones to your friends by tapping Menu>Tones>Manage MIDI Tones.


Ringtone store and Free Ringtones

If you tap on 'Browse ringtone store' you will arrive at a page where you can then continue to the store www.logogo.com. Your phone will need to be able to connect to the web. If your sim card will not let your treo go online, you can still go to this link on your desktop.

5. Announce Caller and EPSpeak

This is a new feature in ringo. Using the technology of an application called 'Epspeak', you can now get your phone to *tell* you who's calling!

To do this, you will need to download



Selecting 'Announce callers' from the menu will activate the epspeak application.

www.electricpocket.com/epspeak.zip and to run it once on your device. Then when in Ringo, to activate it, tap menu>Options>Announce Callers and it will announce all your incoming calls. When you want to switch it off again, do the same Menu>Options and tap on 'Announce Callers' again to deactivate it.



Checking the Picture box and then tapping Select will let you choose a photo from an easy to use Gallery view menu of all your Treo photos.

6. Add Incoming Call Display

Finally you can choose an image to show when you are being called. By ticking the 'Incoming call Display' box labelled 'Picture', you can then tap 'Select' and choose any photos you have saved on your Treo or have on your memory card.



The 'Friend' Screen

7. Ringo Features

Adding and Editing Friends

Add Friend

To add a friend tap on the Friends (👤) view icon, and then on 'New' (see left), you can then personalise a single contact or number to have its own tones and Caller id picture.

If you want to personalise a contact from your Treo Contacts book, tap on 'Name' and then 'Lookup' and then select the contact you want to use. The number will be filled in automatically for you.

You can also choose to personalise a number that is not in your main address book by manually entering the information in the 'Name' and 'Number' fields.

Then you can continue to select SMS and ringtones and a




Creating a New Ring Friend. Tapping on the 'Name' button will look up a contact in your Treo's contact book.



Selecting a Friend from the list then tapping here allows you to change the settings.



Group View



Setting your Group tones.

caller id picture for the newly created Ringo Friend in the same way you do for the default tone. You don't have to have all three settings – for example you can just have a ringtones for a friend, but not an SMS tone or Picture ID. It's up to you.

Editing a friend

You can change the settings for a Ringo Friend at any time by tapping on the 'Friends' icon (👤), highlighting the contact, and then tapping 'edit' (🔧). The screen you first saw when adding the friend then appears and the procedure is the same.

To delete a friend, highlight the entry and then tap on the garbage can icon.

Match all numbers

Ringo will automatically find all the numbers for the contact you are adding as a ringo friend. For example, if you have a friend called 'Bill' who has a home, work and office number all in your contacts list, Ringo will find all 3 and set all of Bill's numbers to have the same ringtone.

Adding and Editing a Group

Any group you have created in your Treo contacts book can be given a Ring Tone, SMS tone and Incoming Call Display also.

If you tap on the 'Groups' icon (👥), select the group you want to then you can edit the Group in the same way you edit or add Friends.

8. Advanced Ringo Features



This icon means this Friend has been set to 'Do Not Disturb'.




Check this box to set a friend to silent.

Do Not Disturb

You will see in both the Friends and Group views, we now have a box that can be checked saying 'Do Not Disturb'. This is our new 'enemies' feature which will let you select contacts that you really don't want to talk to that day to go on silent, and therefore, straight to voicemail.


Tick the box to activate this. Then, all the contacts – groups or friends – who have been set to 'Do Not Disturb' will show up with a mute icon in the group or friends view (see left) so you can easily identify who is and isn't set to silent.

To remove this setting you just need to uncheck the box.



Volume Settings

Ringo will now use the volume settings set in your Treo preferences instead of having to set them separately. You can change your phone volume at any time from Ringo by tapping Menu>Tones>Phone Preferences, you will be taken to your Treo's system volume settings.



This Bullet point indicates the Escalating Ring has been activated.

Ringo Options

Tapping Menu>Options gives you some new features in Ringo, to Announce callers, have an Escalating Ring, and to Disable Ringo.

As with the Announce Callers feature, the Escalating Ring and also the option to disable Ringo can be selected by tapping on them in the menu. When they are activated, a bullet point will show to the left of them (see left). To deactivate them, tap the option you want to turn off and the bullet point will disappear.

These 3 features apply to all your Ringo Groups and contacts.

Escalating Ring

If this is selected the tone will simply get louder in volume the longer it rings. The

Disable Ringo

When selected, this preference will disable all Ringo settings (friends, groups etc) and revert to your default Phone settings set in your Treo's Preferences.

Record Your Own Ringtones

You are no longer limited to music or midi ringtones in Ringo. Now you can record ANY sound to be your tone – the sea, your friend's voice, your dog barking – be creative.

Checking for Updates

If you go to Menu>Help>About Ringo and tap on 'Check for Updates', you can see if your version is the latest and greatest, and download any updates.

9. Registering Ringo

Ringo comes as a free time limited trial.

You can use Ringo up to 7 days for free. If you wish to continue using Ringo after then please purchase a registration code from www.electricpocketshop.com. A code will be sent to you by email.

Tapping on the unlock button will allow you to unlock your version or Ringo at any time. Alternatively, You can enter your registration code when you next launch Ringo (tap Enter Key instead of Trial) or go to Menu>Help>Buying Ringo, and enter the code you received.

